


# Troubleshooting for the DU-01 / CU-02 USB Microphones


## Microsoft Windows Settings to check:

\*Windows XP used for this example


1. Open your **Control Panel**
2. Open **Sounds and Audio Devices**



3. Click the **Audio** tab
4. Under **Sounds recording** choose **USB Studio Microphone** from the **Default device** drop-down menu




5. Click the **Volume** button below the **Default device** drop-down menu
6. In the pop-up window, make sure **Mute all** is not checked
7. Close the pop-up window and click **OK** in the **Sounds and Audio Device Properties** window



## Recording Software Settings to check:

\*AUDACITY used for this example

1. Click **Edit** from the **File Menu**
2. Click **Preferences...**



3. Click the **Audio I/O** tab
4. Check **USB Studio Microphone** from the drop-down menu for the **Recording Device**
5. Click **OK**

